

Only install in specialized workshops.



## **FUEL TANK PROTECTION FI 80**



## **TECHNICAL SPECIFICATIONS:**

DIAMETER	MATERIAL	MOUNTING
» 80mm	» metal	» screws

## **INSTALLATION INSTRUCTIONS:**

Fuel filler protection is a device responsible for protecting the fuel tank against unauthorized access. The protection should be installed in cars whose fuel filler is adapted to the given type of protection and in cars where the fuel filler is fully functional.

The fuel filler locks may only be used for their intended purpose. Only install in specialized workshops.

- 1. Remove the protection from the packaging.
- 2. Place the protector in the filler opening and fit properly.
- 3. Please be safe during use.
- 4. Only stoppers that match the seal should be used.