

HEAD LAMP LED R148 R149 RIGHT

WARNINGS FOR THE USER:

- Do not look directly into the light it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- · Use in open space only.
- · Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- · Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.





www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:



MATERIAL	QUANTITY LED	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 15	» screw	» socket in the lamp » wire 20 cm with plug	» Position » Low beam » High beam » DRL » Indicator	» 4W » 15W » 25W » 12W » 6W	» 12V/24V	» ECE R10 » ECE R148 » ECE R149	» carton dimension: 263x217x141 mm » lamp weight: 1500g » 10 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.