




WORK LAMPS & LED PANELS



REFERENCE:
L0061

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

LED WORKING LAMP CUBE - 2 PCS SET

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 9 » 2762 LM	» screw	» 250mm	» work light » combo	» 45 W	» 12V/24V	» ECE R10	» cart. dim.: 185x170x108 mm » lamp weight: 700 g » 20 sets(40pcs)/ bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
L0068

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.


- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

LED WORK LAMP 5X 3W FLOOD

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 5 » 630 LM	» screw	» 300mm	» work light » flood	» 12W	» 12V/24V	» ECE R10	» cart. dim.: 95x55x120 mm » lamp weight: 216g » 36 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
L0064

LED WORKING LAMP CUBE

WARNINGS FOR THE USER:

Do not look directly into the light - it may cause damage or even loss of vision.
Install only in specialized workshops or professional services.
Use in open space only.
Use in accordance to the purpose.

NEW


INSTALLATION INSTRUCTIONS:

It should be used exclusively in accordance with intended use.
Mount exclusively in specialized workshops.
The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
Do not cut off tinned ends.
Lamps must be installed only in accordance with UNECE regulations.

COUNTRY OF ORIGIN: PRC

www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 12 » 1440 LM	» screw	» 300mm	» work light » flood	» 25W	» 12V/24V	» ECE R10	» carton dimension: 100x90x90 mm » lamp weight: 418g » 40 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
L0074

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

LED WORK LAMP ROUND 4X LED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PMMA » Housing: AL	» 4 » 1600 LM	» screw	» 300mm	» work light » flood	» 16W	» 12V/24V	» ECE R10	» cart. dim.: 125x65x150mm » lamp weight: 390g » 20 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0077S

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 9X LED SQUARE SPOT

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 9 » 1430 LM	» screw	» 300mm	» work light » spot	» 24W	» 12V/24V	» ECE R10	» cart. dim.: 119x65x148 mm » lamp weight: 317g » 20 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0078S

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP SPOT SMALL

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 1 » 805 LM	» screw	» 300mm	» work light » flood	» 4W	» 12V/24V	» ECE R10	» cart. dim.: 92x80x86 mm » lamp weight: 330g » 50 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0078

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP SMALL

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 1 » 805 LM	» screw	» 300mm	» work light » flood	» 4W	» 12V/24V	» ECE R10	» cart. dim.: 92x80x86 mm » lamp weight: 330g » 50 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0081

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 16X LED SQUARE

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 16 » 2100 LM	» screw	» 300mm	» work light » flood	» 43W	» 12V/24V	» ECE R10	» cart. dim.: 119x65x148 mm » lamp weight: 484g » 20 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0081-B

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0081S

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 16X LED SQUARE

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 16 » 2000 LM	» screw	» 300mm	» work light	» 24W	» 12V/24V	» ECE R10	» cart. dim.: 119x65x148 mm » lamp weight: 402g » 20 pcs/bulk carton

R10

IP67

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0082

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 16X LED SQUARE

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 4 » 1000 LM	» screw	» 250mm	» work light » flood	» 16W	» 12V/24V	» ECE R10	» cart. dim.: 140x100x90 mm » lamp weight: 450g » 20 pcs/bulk carton

R10

IP67

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

LED WORK LAMP 16X LED SQUARE

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 16 » 2100 LM	» screw	» 300mm	» work light » spot	» 43W	» 12V/24V	» ECE R10	» cart. dim.: 119x65x148 mm » lamp weight: 484g » 20 pcs/bulk carton

R10

IP67

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0089

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 15X LED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PMMA » Housing: AL	» 15 » 1720 LM	» screw	» 300mm	» work light » flood	» 26W	» 12V/24V	» ECE R10	» cart. dim.: 170x130x100 mm » lamp weight: 910g » 20 pcs/bulk carton

R10

IP67

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0125

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0151

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:


Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0128

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0152

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0128

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0152

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:



Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0153

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 12X LED ROUND WITH SWITCH OFF/ON

PHOTO AND TECHNICAL DRAWING:



OFF/ON



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 12 » 1800 LM	» screw	» 250mm	» work light » flood » switch	» 12W	» 12V/24V	» ECE R10	» cart. dim.: 87x56.5x94mm » lamp weight: 280g » 40 pcs/bulk carton

IP67

R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0155

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 16X LED ROUND WITH SWITCH OFF/ON

PHOTO AND TECHNICAL DRAWING:



OFF/ON



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 16 » 2400 LM	» screw	» 250mm	» work light » flood » switch	» 16W	» 12V/24V	» ECE R10	» cart. dim.: 102x55.5x109 mm » lamp weight: 350g » 40 pcs/bulk carton

IP67

R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0154

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 16X LED SQUARE WITH SWITCH OFF/ON

PHOTO AND TECHNICAL DRAWING:



OFF/ON



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 16 » 2400 LM	» screw	» 250mm	» work light » flood » switch	» 16W	» 12V/24V	» ECE R10	» cart. dim.: 102x55.5x109 mm » lamp weight: 350g » 40 pcs/bulk carton

IP67

R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0156

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 30X LED SQUARE WITH SWITCH OFF/ON

PHOTO AND TECHNICAL DRAWING:



OFF/ON



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PS » Housing: AL	» 30 » 3800 LM	» screw	» 250mm	» work light » flood » switch	» 30W	» 12V/24V	» ECE R10	» cart. dim.: 212x66.5x148 mm » lamp weight: 610g » 20 pcs/bulk carton

IP67

R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L0157

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0157

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:



Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0158L

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0158L

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:


Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0158R

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0158R

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:


Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0159

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L0159

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP CORNER RIGHT

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: PVC	» Front + side: 22pc » Rear: 18pcs » 1350 LM	» screw	» 250mm	» work light » flood	» Front + side: 10W » Rear: 9W	» 12V/24V	» ECE R10	» cart. dim.: 302x66x102 mm » lamp weight: 400g » 20 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

LED WORK LAMP CORNER LEFT

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: PVC	» Front + side: 22pc » Rear: 18pcs » 1350 LM	» screw	» 250mm	» work light » flood	» Front + side: 10W » Rear: 9W	» 12V/24V	» ECE R10	» cart. dim.: 302x66x102 mm » lamp weight: 400g » 20 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

RECHARGEABLE LED WORK LAMP WITH MAGNET

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 9	» magnet » hand holder	» AC adaptor cigar plug 1m USB cable	» work light 100% or 50% intensity, » SOS flash, » Quad flash.	» 9W	» battery 3,7V 4400mAh	» CE	» cart. dim.: 120x120x230 mm » lamp weight: 690 g » 20 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

myKAMAR

REFERENCE:
L0177

WORK LAMP 9XLED SQUARE PLUS

WARNINGS FOR THE USER:

- Do not look directly into the light - it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.

COUNTRY OF ORIGIN: PRC

TRUCK LED

T

www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 9 » 1133 LM	» screw	» 250mm	» work light » flood	» 20W	» 12V/24V	» ECE R10	» carton dimension: 119x65x148 mm » lamp weight: 290g » 20 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

myKAMAR

REFERENCE:
L0179

WORK LAMP 3XLED TRIANGLE

WARNINGS FOR THE USER:

- Do not look directly into the light - it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.

COUNTRY OF ORIGIN: PRC

TRUCK LED

T

www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 3 » 911 LM	» screw	» 250mm	» work light » flood	» 9W	» 12V/24V	» ECE R10	» carton dimension: 85x70x70 mm » lamp weight: 220g » 60 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

myKAMAR

REFERENCE:
L0178

WORK LAMP 16XLED SQUARE PLUS

WARNINGS FOR THE USER:

- Do not look directly into the light - it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.

COUNTRY OF ORIGIN: PRC

TRUCK LED

T

www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 16 » 1711 LM	» screw	» 250mm	» work light » flood	» 25W	» 12V/24V	» ECE R10	» carton dimension: 119x65x148 mm » lamp weight: 315g » 20 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

myKAMAR

REFERENCE:
L0180

WORK LAMP 6XLED 12/24V

WARNINGS FOR THE USER:

- Do not look directly into the light - it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.

COUNTRY OF ORIGIN: PRC

TRUCK LED

T

www.myKAMAR.com

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 6 » 1200 LM	» screw	» 250mm	» work light » spot	» 18W	» 12V/24V	» ECE R10	» carton dimension: 196x78x52 mm » lamp weight: 1050g » 20 pcs/bulk box

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
L2204

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
L2205

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

LED WORK LAMP 5 LED, 10-30V

PHOTO AND TECHNICAL DRAWING:



R10

UNECE Regulation 10 Approved



MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 5 » 500 LM	» screw	» 400mm	» work light » flood	» 14W	» 12V/24V	» ECE R10	» cart. dim.: 150x130x50mm » lamp weight: 480g » 40 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

LED WORK LAMP ROUND 6 LED

PHOTO AND TECHNICAL DRAWING:



R10

UNECE Regulation 10 Approved



MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 6 » 570 LM	» screw	» 400mm	» work light » flood	» 15W	» 12V/24V	» ECE R10	» cart. dim.: 150x130x50mm » lamp weight: 480g » 40 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



LED PANELS



REFERENCE:
LB0002

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 10X LED 273MM

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 12 » 920LM	» screw	» 300 mm	» work light » combo	» 22 W	» 12V/24V	» ECE R10	» cart. dim.: 230x110x130 mm » lamp weight: 1050 g » 10 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0003

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 20X LED 375MM

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 20 » 1533LM	» screw	» 300 mm	» work light » combo	» 36 W	» 12V/24V	» ECE R10	» cart. dim.: 330x110x130 mm » lamp weight: 1350 g » 8 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps.While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0004

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 40X LED 630MM

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKAGE/ WEIGHT
» Lens: PC » Housing: AL	» 40 » 4453 LM	» screws	» 250mm	» work light » combo	» 120 W	» 12V/24V	» ECE R10	» cart. dim: 680x120x120 mm » lamp weight: 2850 g » 4 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



www.truck-kamar.pl



REFERENCE:
LB0005

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 60X LED 885MM

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKAGE/ WEIGHT
» Lens: PC » Housing: AL	» 60 » 6527 LM	» screws	» 250mm	» work light » combo	» 180 W	» 12V/24V	» ECE R10	» cart. dim.: 930x120x120 mm » lamp weight: 3450 g » 4 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



www.truck-kamar.pl



REFERENCE:
LB0004V

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 40X LED 630MM CURVED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKAGE/ WEIGHT
» Lens: PC » Housing: AL	» 40 » 4964 LM	» screws	» 250mm	» work light » combo » larger viewing angle	» 120 W	» 12V/24V	» ECE R10	» cart. dim.: 680x120x120 mm » lamp weight: 2500 g » 4 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



www.truck-kamar.pl



REFERENCE:
LB0005V

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 60X LED 885MM CURVED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKAGE/ WEIGHT
» Lens: PC » Housing: AL	» 60 » 6700 LM	» screws	» 250mm	» work light » combo » larger viewing angle	» 180 W	» 12V/24V	» ECE R10	» cart. dim.: 930x120x120 mm » lamp weight: 3360 g » 4 pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



www.truck-kamar.pl



REFERENCE:
LB0025

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0027

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0027

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0026

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0028

COUNTRY OF ORIGIN: PRC



WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0028

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0028

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



PANEL LED 36W 167MM FLOOD

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

R10

UNECE Regulation 16 Approved

IP67


Waterproof

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 12 » 1400 LM	» screw	» 300mm	» work light » flood	» 24W	» 12V/24V	» ECE R10	» cart. dim.: 240x120x100 mm » lamp weight: 434g » 20pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or part of the catalog without written authorization is prohibited.



PANEL LED 36W 167MM COMBO RIGHT

PHOTO AND TECHNICAL DRAWING:

» flood » spot

165
38
65

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 12 » 1400 LM	» screw	» 300mm	» work light » flood/spot	» 24W	» 12V/24V	» ECE R10	» cart dim.: 240x120x100 mm » lamp weight: 434g » 20pcs/bulk box

R10
UNECE Regulation 9 Approved

IP67

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



PANEL LED 36W 167MM COMBO LEFT

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 12 » 1400 LM	» screw	» 300mm	» work light » flood/spot	» 24W	» 12V/24V	» ECE R10	» cart. dim.: 240x120x100 mm » lamp weight: 434g » 20pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



167MM LED PANEL 36W SPOT

PHOTO AND TECHNICAL DRAWING:


TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 12 » 1400 LM	» screw	» 300mm	» work light » spot	» 24W	» 12V/24V	» ECE R10	» cart. dim.: 240x120x100 mm » lamp weight: 434g » 20pcs/bulk box

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 24 » 3767 LM	» screw	» 250mm	» work light » combo	» 72W	» 12V/24V	» ECE R10	» cart. dim.: 240x190x160 mm » lamp weight: 1700g » 8 pcs/bulk carton

REFERENCE:
LB0045




Technical drawing of the LED light bar showing a perspective view and two side views with dimensions:

- Perspective View:** Shows the light bar with 30 LEDs arranged in two rows of 15.
- Top View:** Shows the light bar with dimensions 305mm (total length) and 269mm (internal length).
- Side View:** Shows the light bar with dimensions 93mm (height) and 167mm (depth).
- Bottom View:** Shows the light bar with dimensions 120mm (width) and 167mm (depth).




MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 48 » 6473 LM	» screw	» 250mm	» work light » combo	» 144W	» 12V/24V	» ECE R10	» cart. dim.: 580x190x180 mm » lamp weight 3200g » 6 pcs/bulk carton

REFERENCE:
LB0044




A black, rectangular LED work light with a mounting bracket and a power cable. The light features a grid of 24 individual LED chips arranged in two rows of 12. It is mounted on a black base with a swivel joint. A black power cable is attached to the side.



MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/ WEIGHT
» Lens: PC » Housing: AL	» 36 » 5032 LM	» screw	» 250mm	» work light » combo	» 108W	» 12V/24V	» ECE R10	» cart. dim.: 310x190x160 mm » lamp weight: 2600g » 6 pcs/bulk carton

REFERENCE:
LB0046




MATERIAL	LED/LM QUANTITY	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 60 » 7056 LM	» screw	» 250mm	» work light » combo	» 180W	» 12V/24V	» ECE R10	» cart. dim: 440x180x145 mm » lamp weight 3400g » 6 pcs/bulk carton



REFERENCE:
LB0071

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 18X LED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 18 » 5850 LM	» screw	» 500 mm	» work light » combo	» 132 W	» 12V/24V	» ECE R10	» cart. dim.: 940x140x120 mm » lamp weight: 3550g » 4 pcs/bulk box



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0073

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.


- Use in accordance to the purpose.



www.truck-kamar.pl


PANEL LED 6X LED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 6 » 1950 LM	» screw	» 500 mm	» work light » flood	» 48 W	» 12V/24V	» ECE R10	» cart. dim.: 590x140x120mm » lamp weight: 1950g » 12 pcs/bulk box



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0072

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 26X LED

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 26 » 8450 LM	» screw	» 500 mm	» work light » combo	» 190 W	» 12V/24V	» ECE R10	» cart. dim.: 1170x140x120 mm » lamp weight: 4730 g » 4 pcs/bulk box



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0074

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl

PANEL LED 18XLED SPOT

PHOTO AND TECHNICAL DRAWING:



TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 18 » 1200 LM	» screw	» 300 mm	» work light » spot	» 27 W	» 12V/24V	» ECE R10	» cart. dim.: 55x45x200 mm » lamp weight: 215 g » 50pcs/bulk box



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in airy places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.



REFERENCE:
LB0087

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.


-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0089

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:



Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0088

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0090

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0087

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0089

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0088

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0090

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0087

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



REFERENCE:
LB0089

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.



www.truck-kamar.pl



WARNINGS FOR THE USER:



PHOTO AND TECHNICAL DRAWING:



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps! While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in air places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations



WARNINGS FOR THE USER:



PHOTO AND TECHNICAL DRAWING:



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations



WARNINGS FOR THE USER:



PHOTO AND TECHNICAL DRAWING:



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions for personal safety and durability of the products. The device must be installed on / of each of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting, you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in air places. The installation should be made by professional workshop of specialized service. Users manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations



WARNINGS FOR THE USER:



PHOTO AND TECHNICAL DRAWING:



INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out to each child. If you would like to change the existing incandescent/halogen lighting on LED lighting, the installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations

REFERENCE:
LB0095

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

PANEL LED 200XLED

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 200x LED » 13000 LM	» screw	» 300 mm	» work light » combo	» 300W	» 12V/24V	» ECE R10	» cart. dim.: 132x115x830 mm » lamp weight: 1395g » 6 pcs/bulk box

IP67 R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
LB0097

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

PANEL LED 20XLED + 72XLED STIPE+ DT CONNECTOR

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 20+72 » 12690 LM » 16 LM	» screws	» 250mm with DT connector	» work light » combo » LED strip	» 178W + 10W	» 12V/24V	» ECE R10	» cart. dim.: 1160x110x68 mm » lamp weight: 3900g » 4 pcs/bulk box

IP67 R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
LB0096

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!
-Do not look directly into the light - it may cause damage or even loss of vision.

-Install only in specialized workshops or professional services.

- Use in open space only.

- Use in accordance to the purpose.

www.truck-kamar.pl

PANEL LED 16+57 LED STIPE+ DT CONNECTOR

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	CABLE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING/WEIGHT
» Lens: PC » Housing: AL	» 16+57 » 10279 LM » 16 LM	» screws	» 250mm with DT connector	» work light » combo » LED strip	» 124W + 10W	» 12V/24V	» ECE R10	» cart. dim.: 960x110x68mm » lamp weight: 3000g » 4 pcs/bulk box

IP67 R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

REFERENCE:
LB0098

PANEL LED BEZEL-LESS 36+72 LED STRIPE + DT CONNECTOR

WARNINGS FOR THE USER:

• Do not look directly into the light - it may cause damage or even loss of vision.

• Install only in specialized workshops or professional services.

• Use in open space only.

• Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

• It should be used exclusively in accordance with intended use.

• Mount exclusively in specialized workshops.

• The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.

• Do not cut off tinned ends.

• Lamps must be installed only in accordance with UNECE regulations.

www.myKAMAR.com

REFERENCE:
LB0098

PHOTO AND TECHNICAL DRAWING:

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 36+72 » 612 LM » 12212 LM	» screws 2 types	» 250mm » DT connector	» work light » combo » LED stripe White + Amber	» 13W » 140W	» 12V/24V	» ECE R10	» carton dimension: 920x111x93 mm » lamp weight: 4000g » 4 pcs/bulk box

IP67 R10

TECHNICAL SPECIFICATIONS:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTIFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 36+72 » 612 LM » 12212 LM	» screws 2 types	» 250mm » DT connector	» work light » combo » LED stripe White + Amber	» 13W » 140W	» 12V/24V	» ECE R10	» carton dimension: 920x111x93 mm » lamp weight: 4000g » 4 pcs/bulk box

IP67 R10

INSTALLATION INSTRUCTIONS:

LED work lamp used to illuminate the working area in vehicles off the public roads. For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. Use in any places. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Lamps must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

myKAMAR

REFERENCE:
LB0099

PANEL LED BEZEL-LESS 48+96
LED STRIPE+ DT CONNECTOR

WARNINGS FOR THE USER:

- Do not look directly into the light - it may cause damage or even loss of vision.
- Install only in specialized workshops or professional services.
- Use in open space only.
- Use in accordance to the purpose.

INSTALLATION INSTRUCTIONS:

- It should be used exclusively in accordance with intended use.
- Mount exclusively in specialized workshops.
- The connection between the lamp and vehicle's installation should be isolated with heat-shrink tube or alternatively with isolating tape to avoid getting water and moisture to the copper wire of the lamp which can damage electronic components. When it comes to lamp and plug, the plug should be mounted safely.
- Do not cut off tinned ends.
- Lamps must be installed only in accordance with UNECE regulations.

TRUCK LED T

www.myKAMAR.com

COMING SOON

PHOTO AND TECHNICAL DRAWING:

MATERIAL	QUANTITY LED/LM	MOUNTING	WIRE	FUNCTION	WATT	VOLTAGE	CERTYFICATES	PACKING WEIGHT
» Lens: PC » Housing: AL	» 48+96 » 700 LM » 15000 LM	» screws 2 types	» 250mm » DT connector	» work light » combo » LED stripe White + Amber	» 15W » 180W	» 12V/24V	» ECE R10	» carton dimension: 1100x111x93 mm » lamp weight: 5250g » 4 pcs/bulk box

CABLE	WATT	VOLTAGE	RELAY	FUSE	PACKING/ WEIGHT
» 2x2500mm	» maximum lamp power 120W	» 12V	» 40A	» 30A	» cart. dim: 100x100x100 mm » lamp weight: 250g » 50 pcs/bulk carton

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

KAMAR

REFERENCE:
LB0062-2

WIRE HARDNESS FOR WORK
LAMPS 2X2,5M 12V

WARNINGS FOR THE USER:

Warning!

- Install only in specialized workshops or professional services.
- Use in accordance to the purpose.

TRUCK LED T

www.truck-kamar.pl

COMING SOON

TECHNICAL SPECIFICATIONS:

CABLE	WATT	VOLTAGE	RELAY	FUSE	PACKING/ WEIGHT
» 2x2500mm	» maximum lamp power 120W	» 12V	» 40A	» 30A	» cart. dim: 100x100x100 mm » lamp weight: 250g » 50 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Goods must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

KAMAR

REFERENCE:
LB0062

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

- Install only in specialized workshops or professional services.
- Use in accordance to the purpose.

TRUCK LED T

www.truck-kamar.pl

WIRE HARDNESS FOR WORK LAMPS 12V

TECHNICAL SPECIFICATIONS:

CABLE	WATT	VOLTAGE	RELAY	FUSE	PACKING/ WEIGHT
» 3000mm	» maximum lamp power 120W	» 12V	» 40A	» 30A	» cart. dim: 100x100x100 mm » lamp weight: 250g » 50 pcs/bulk carton

INSTALLATION INSTRUCTIONS:

For proper installation and use of lights it is advisable to read the instructions to ensure personal safety and durability of the products. The device must be installed out of reach of children. The appliance must be fitted out of reach of children. If you would like to change the existing incandescent/halogen lighting on LED lighting - installation does not require to make any changes, except replacing the lamps. While installing new / additional LED lighting you must verify the current capacity of the switch to which you are going to connect the lamp. If you exceed the current carrying capacity of the switch to which you want to connect LED lighting, use an additional relay - the installation of lamps should make a professional engineer. The installation should be made by professional workshop of specialized service. User's manual available for download at www.truck-kamar.pl. Goods must be installed only in accordance with UNECE regulations.

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

KAMAR

REFERENCE:
AKC8002

COUNTRY OF ORIGIN: PRC

WARNINGS FOR THE USER:

Warning!

- Install only in specialized workshops or professional services.
- Use in accordance to the purpose.

TRUCK LED T

www.truck-kamar.pl

DECORATION MOUNTING FOR LED WORK LAMPS

PHOTO AND TECHNICAL DRAWING:

We reserve the right to change technical data and any errors. Photos and specifications are for reference only, and the actual product may vary slightly. Reproduction in whole or parts of the catalog without written authorization is prohibited.

KAMAR S.K.A.

Al. Armii Krajowej 254
85-689 Bydgoszcz
Polska

NIP 554-039-23-83
REGON 093051226

tel: /+48 / 52 326 71 50
fax: /+48 / 52 326 71 58
info@truck-kamar.pl